

■ **GM/GS uyumlu Standart MIDI File'leri kaydederken dikkat edilmesi gerekenler**

G-800'ün kayıt ünitesinde (disket sürücüsünde) GM uyumlu SMF'leri kaydederken dikkat etmeniz gereken hususlar aşağıdaki tabloda belirtilmiştir. Bu hususlara dikkat etmezseniz SMF'ler bir GM modülünde beklediğiniz şekilde playback yapmayacaktır. Bu nedenle disket, format ve ton tipleri için yalnızca aşağıda belirtilenleri kullanın:

Disket tipi	Yalnızca DD
Format	DOS
Tonlar	Yalnızca GM sound'ları (Ton listesine bakınız)

Eğer şarkınızı GS uyumlu bir Standart MIDI File olarak kaydetmek istiyorsanız yukarıda belirtilenleri kullanın - ancak yalnızca GS tonlarını kullanın.

Not: G-800'deki bir stil kayıt esnasında akompanya olarak kullanılacaksa bu stil yalnızca GM/GS ton listesinde kullanılan tonları kullanmalıdır. G-800'de GM veya GS formatlarında mevcut olmayan tonlar da bulunduğundan, bu tonları kayıttan önce eşdeğeri veya benzeri olan GM/GS tonları ile değiştirin. Sayfa 48'de belirtilen "Aranjör partileri için farklı tonların seçimi" bölümüne bakınız.

■ **G-800'e Yüklenebilen User Stiller**

Disket tipi	DD/HD
Format	DOS/Atari
Stil Formatı	MSA (KR serisi, Atelier), MSD (E-86, E-66, RA-95), MSE (G-800)

■ **G-800'deki Stillerin formatı**

Disket tipi	DD/HD
Format	DOS
Stil Formatı	MSE (G-800), eski modellere yüklenemez.

■ **Performans Hafızalarına yüklenebilen datalar**

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	E-86'nın User program'ları, G-800'ün performans programları

■ **G-800'deki performans programlarının formatı**

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	Yalnızca G-800'ün performans hafızalarına yüklenebilir.

■ G-800'e yüklenebilen MIDI Setleri

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	E-86 tipi MIDI Setleri, G-800 tipi MIDI Setleri

■ G-800'deki MIDI Setlerinin formatı

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	Yalnızca G-800 tipi MIDI hafızaları için

■ G-800'e yüklenebilen şarkı setleri

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	E-86 tipi Şarkı Setleri, G-800 tipi şarkı setleri

■ G-800'de şarkı setlerinin formatı

Disket tipi	DD/HD
Format	DOS
Data Formatı	Yalnızca G-800 tipi Şarkı Setleri için

■ G-800'e yüklenebilen Stil Setleri

Disket tipi	DD/HD
Format	DOS/Atari
Data Formatı	E-86 tipi Stil Setleri, G-800 tipi Stil Setleri

■ G-800'deki Stil Setlerinin formatı

Disket tipi	DD/HD
Format	DOS
Data Formatı	Yalnızca G-800 tipi Stil Setleri için

■ Akor Sequencer'ının formatı (okuma ve kayıt)

Disket tipi	DD/HD
Format	DOS
Data Formatı	Yalnızca G-800 tipi Akor Sequencer'ı dataları için

15. Ton Listeleri

15.1 G-800 Ton Listesi (A & B Bankaları)

PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark
Piano										Strings / orchestra				
001	000	Piano 1	1		017	000	Detuned Acc2	2	G-800	041	000	Violin	1	
008	000	Piano 1w	1		024	000	Accordion 1	2	G-800	008	008	Slow Violin	1	
016	000	Piano 1d	1		025	000	Accordion 2	2	G-800	042	000	Viola	1	
002	000	Piano 2	1		001	000	Harmonica	1		043	000	Celllo	1	
008	000	Piano 2w	1		001	000	Harmonica 2	2		044	000	Contrabass	1	
003	000	Piano 3	1		008	000	Bandoneon	1		045	000	Tremolo Str	1	
001	000	EG+Rhodes 1	2							008	008	Slow Tremolo	1	
002	000	EG+Rhodes 2	2							009	009	Suspense Str	2	
008	000	Piano 3w	1		Guitar					046	000	PizzicatoStr	1	
004	000	Honky-tonk	2		025	000	Nylon-str.Gt	1		047	000	Harp	1	
008	000	Old Upright	2		008	008	Ukulele	1		048	000	Timpani	1	
005	000	E.Piano 1	2		016	000	Nylon Gt.o	2		Ensemble				
008	000	St.Soft EP	2		024	000	Velo Harmnix	1	V-SW	049	000	Strings	1	
009	000	SA E. Piano	2	G-800	032	000	Nylon Gt.2	1		001	001	Strings 2	1	
016	000	FM+SA EP	2		040	000	Leguint Gt.	1		008	008	Orchestra	2	
017	000	Stiky Rhodes	2	G-800	000	000	Steel-str.Gt	1		009	009	Orchestra 2	2	
024	000	60's E.Piano	1		008	008	12-str.Gt	2		010	010	Tremolo Orch	2	
025	000	Hard Rhodes	2		009	009	Nylon+Steel	2		011	011	Choir Str.	2	
026	000	MellowRhodes	2		016	016	Mandolin	2		016	016	St.Strings	2	
027	000	60's Piano 2	2	G-800	017	017	Mandolin 2	1	G-800	024	024	Velo Strings	2	
006	000	E.Piano 2	2		018	018	Mandolin Trem	1	G-800	032	032	Strings Oct	2	G-800
008	000	Detuned EP 2	2		032	032	Steel Gt.2	1		050	000	Slow Strings	1	
016	000	St.FM EP	2		027	000	Jazz Gt.	1	*	001	001	SlowStrings2	1	
024	000	Hard FM EP	2		001	001	Mellow Gt	2		008	008	Legato Str.	2	
007	000	Harpichord	1		008	008	Podal Steel	1		009	009	Warm Strings	2	
008	000	Coupled Hps.	2		028	000	Clean Gt.	1		010	010	St.Slow Str.	2	
016	000	Harpis.w	1		001	001	Clean Gt.2	2	G-800	051	000	Syn.Strings1	2	
024	000	Harpis.o	2		002	002	OpenHard Gt	2	G-800	001	001	OB Strings	2	
008	000	Clav.	1		008	008	Chorus Gt.	2		008	008	Syn.Strings3	2	
Chromatic percussion					009	009	JC Strat Gt	2	G-800	052	000	Syn.Strings2	2	
009	000	Celesta	1		029	000	Muted Gt.	1		053	000	Choir Aahs	1	
010	000	Glockenspiel	1		001	001	Muted Dis.Gt	1		008	008	St.Choir	2	
011	000	Music Box	1		002	002	Muted GT 2	1	G-800	009	009	Mello Choir	2	
012	000	Vibraphone	1		008	008	Funk Pop	1		032	032	Choir Aahs 2	1	
001	000	Hard Vibe	2		016	016	Funk Gt.2	1	V-SW	054	000	Voice Oohs	1	
008	000	Vib.w	1		030	000	Overdrive Gt	1		055	000	SynVox	1	
013	000	Marimba	1		031	000	DistortionGt	1		008	008	Syn.Voice	2	
008	000	Marimba w	1		001	001	Dist. Gt2	2		056	000	OrchestraHit	2	
016	000	Barafon	1		002	002	Dazed Guitar	2		008	008	Impact Hit	2	
017	000	Barafon 2	1		008	008	Feedback Gt.	2		009	009	Philly Hit	2	
024	000	Log drum	1		009	009	Feedback Gt.2	2		010	010	Double Hit	2	
014	000	Xylophone	1		016	016	Power Guitar	2		016	016	Lo Fi Rave	2	
015	000	Tubular-bell	1		017	017	Power Gt.2	2		Brass				
008	000	Church Bell	1		018	018	5th Dist.	2		057	000	Trumpet	1	
009	000	Carillon	1		024	024	Rock Rhythm	2		001	001	Trumpet 2	1	
016	000	Santur	1		025	025	Rock Rhythm2	2		008	008	Flugel Horn	1	
001	000	Santur 2	2		032	000	Gt.Harmonics	1		024	024	Bright Tp.	2	
008	000	Cimbalom	2		008	008	Gt. Feedback	1		025	025	Warm Tp.	2	
Organ					016	016	Ac.Gt.Harmnx	1		058	000	Trombone	1	
017	000	Organ 1	1		Bass					001	001	Trombone 2	2	
001	001	Organ 101	2		033	000	Acoustic Bs.	2		059	000	Tuba	1	
008	000	Detuned Or.1	2		034	000	Fingered Bs.	1		001	001	Tuba 2	1	
009	000	Organ 109	2		001	001	Fingered Bs2	2		060	000	MutedTrumpet	1	
016	000	60's Organ 1	1		002	002	Jazz Bass	1		061	000	French Horns	1	V-SW
017	000	60's Organ 2	1		035	000	Picked Bass	1		001	001	Fr.Horn 2	2	
018	000	60's Organ 3	1		008	008	Mute PickBs	1		008	008	Fr.Horn Solo	1	
024	000	Cheese Organ	1		036	000	Fretless Bs.	1		016	016	Horn Orch	2	
032	000	Organ 4	1		001	001	Fretless Bs2	2		062	000	Brass 1	1	*
033	000	Even Bar	2		002	002	Fretless Bs3	2		008	008	Brass 2	2	
040	000	Organ Bass	1		003	003	Fretless Bs4	2		016	016	Brass Fall	1	
048	000	Organ Oct 1	2	G-800	004	004	Syn Fretless	2		024	024	Brass Oct	2	G-800
018	000	Organ 2	1		005	005	Mr.Smooth	2		063	000	Synth Brass1	2	
001	001	Organ 201	2		037	000	Slap Bass 1	1		001	001	Poly Brass	2	
008	000	Detuned Or.2	2		008	008	Reso Slap	1		008	008	Synth Brass3	2	
032	000	Organ 5	2		038	000	Slap Bass 2	2		009	009	Quack Brass	2	
019	000	Organ 3	2		039	000	Synth Bass 1	2		016	016	Octave Brass	2	
008	000	Rotary Org.	1	V-SW	001	001	SynthBass101	1		064	000	Synth Brass2	2	
016	000	Rotary Org.S	1		008	008	Acid Bass	1		001	001	Soft Brass	2	
024	000	Rotary Org.F	1		009	009	TB303 Bass	1		008	008	Synth Brass4	1	
020	000	Church Org.1	1		010	010	Tekno Bass	2		016	016	Velo Brass 1	2	
008	000	Church Org.2	2		016	016	Reso SH Bass	1		017	017	Velo Brass 2	2	
009	000	Organ Oct 2	2	G-800	040	000	Synth Bass 2	2		Reed				
016	000	Church Org.3	2		001	001	SynthBass201	2		065	000	Soprano Sax	1	
024	000	Organ Flute	1		002	002	Modular Bass	2		066	000	Alto Sax	1	
032	000	Trem.Flute	2		003	003	Seq Bass	2		008	008	Hyper Alto	1	V-SW
021	000	Reed Organ	1	*	008	008	Beet FM Bass	2		009	009	Alto Sax 2	1	G-800 V-SW
022	000	Accordion Fr	1		009	009	X Wire Bass	2						
008	000	Accordion It	2		016	016	Rubber Bass	2						
016	000	Detuned Acc	2	G-800	017	017	SH101 Bass 1	1						
					018	018	SH101 Bass 2	1						
					019	019	Smooth Bass	2						

*: Same sound as in SC-55 map. **: Percussive sound which cannot be played melodically, use a note near C4 (note number 60).

PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark
067	000	Tenor Sax	2		001		Harmo Rain	2		011		St.Gamelan	2	
001		Tenor Sax 2	1	G-800 V-SW	002		African wood	2		016		RAMA Cymbal	1	
008		BreathyTenor	1		008		Clavi Pad	2		114	000	Agogo	1	
068	000	Baritone Sax	1		098	000	Soundtrack	2		008		Atarigane	1	
069	000	Oboe	1		001		Ancestral	2		115	000	Steel Drums	1	
070	000	English Horn	1		002		Prologue	2		116	000	Woodblock	1	
071	000	Bassoon	1		008		Rave	2		008		Castanets	1	
072	000	Clarinet	1		099	000	Crystal	2		117	000	Taiko	1	
008		Bs Clarinet	1		001		Syn Mallet	1		008		Concert BD	1	
<i>Pipe</i>					002		Soft Crystal	2		118	000	Melo. Tom 1	1	
073	000	Piccolo	1		003		Round Glock	2		001		Real Tom	2	
008		Nay	1	G-800	004		Loud Glock	2		008		Melo. Tom 2	1	
009		Nay Oct	2	G-800	005		GlockenChime	2		009		Rock Tom	2	
074	000	Flute	1		006		Clear Bells	2		119	000	Synth Drum	1	
075	000	Recorder	1		007		ChristmasBel	2		008		808 Tom	2	
076	000	Pan Flute	2		008		Vibra Bells	2		009		Elec Perc	1	
008		Kawala	2		009		Digi Bells	2		120	000	Reverse Cym.	1	
009		Kawala 2	1	G-800	016		Choral Bells	2		001		Reverse Cym2	1	
010		Kawala Oct	2	G-800	017		Air Bells	2		008		Rev.Snare 1	1	
077	000	Bottle Blow	2		018		Bell Harp	2		009		Rev.Snare 2	1	
078	000	Shakuhachi	2		019		Gamelimba	2		016		Rev.Kick 1	1	
079	000	Whistle	1		100	000	Atmosphere	2		017		Rev.ConBD	1	
080	000	Ocarina	1		001		Warm Atmos	2		024		Rev.Tom 1	1	
<i>Synth Lead</i>					002		Nylon Harp	2		025		Rev.Tom 2	1	
081	000	Square Wave	2		003		Harpvox	2		<i>SFX</i>				
001		Square	1		004		HollowReleas	2		121	000	Gt.FretNoise	1	
002		Hollow Mini	1		005		Nylon+Rhodes	2		001		Gt.Cut Noise	1	
003		Mellow FM	2		006		Ambient Pad	2		002		String Slap	1	
004		CC Solo	2		101	000	Brightness	2		003		Gt.CutNoise2	1	
005		Shmoog	2		102	000	Goblin	2		004		Dist.CutNoiz	1	
006		LM Square	2		001		Goblinson	2		005		Bass Slide	1	
008		Sine Wave	1		002		50's Sci-Fi	2		006		Pick Scrape	1	
082	000	Saw Wave	2		103	000	Echo Drops	1		122	000	Breath Noise	1	
001		Saw	1		001		Echo Bell	2		001		Fl.Key Click	1	
002		Pulse Saw	2		002		Echo Pan	2		123	000	Seashore	1	
003		Feline GR	2		003		Echo Pan 2	2		001		Rain	1	
004		Big Lead	2		004		Big Panner	2		002		Thunder	1	
005		Velo Lead	2		005		Reso Panner	2		003		Wind	1	
006		GR-300	2		006		Water Piano	2		004		Stream	2	
007		I.A Saw	1		104	000	Star Theme	2		005		Bubble	2	
008		Doctor Solo	2		001		Star Theme 2	2		124	000	Bird	2	***
016		Waspy Synth	2		<i>Ethnic, etc.</i>					001		Dog	1	***
083	000	Syn.Calliope	2		105	000	Sitar	1		002		Horse-Gallop	1	***
001		Vent Synth	2		001		Sitar 2	2		003		Bird 2	1	***
002		Pure PanLead	2		002		Detune Sitar	2		004		Kitty	1	**
084	000	Chiffer Lead	2		008		Tambra	1		005		Growl	1	**
085	000	Charang	2		016		Tamboura	2		125	000	Telephone 1	1	***
008		Dist. Lead	2		106	000	Banjo	1		001		Telephone 2	1	***
086	000	Solo Vox	2		001		Muted Banjo	1		002		DoorCreaking	1	***
087	000	5th Saw Wave	2		008		Rabab	2		003		Door	1	***
001		Big Fives	2		016		Gupichant	2		004		Scratch	1	***
088	000	Bass & Lead	2		024		Oud	2		005		Wind Chimes	2	***
001		Big & Raw	2		025		Oud 2	1	G-800	007		Scratch 2	1	**
002		Fat & Perky	2		026		Oud Tremolo	1	G-800	126	000	Helicopter	1	***
<i>Synth Pad, etc.</i>					027		Oud V-Switch	2	G-800	001		Car-Engine	1	***
089	000	Fantasia	2		028		Oud & Strings	2	G-800	002		Car-Stop	1	***
001		Fantasia 2	2		107	000	Shamisen	1		003		Car-Pass	1	***
090	000	Warm Pad	1		001		Tsugaru	2		004		Car-Crash	2	***
001		Thick Pad	2		108	000	Koto	1		005		Siren	1	***
002		Horn Pad	2		008		Taisho Koto	1		006		Train	1	***
003		Rotary Strng	2		016		Kanoon	2		007		Jetplane	2	***
004		Soft Pad	2		017		Kanoon 2	1	G-800	008		Starship	2	***
091	000	Poly-synth	2		018		Kanoon Oct	2	G-800	009		Burst Noise	2	***
001		80's PolySyn	2		019		Kanoon & Choir	2	G-800	127	000	Applause	2	***
092	000	Space Voice	1		109	000	Kalimba	1		001		Laughing	1	***
001		Heaven II	2		110	000	Bagpipe	1		002		Screaming	1	***
093	000	Bowed Glass	2		008		Mizmar	1	G-800	003		Punch	1	***
094	000	Metal Pad	2		009		Mizmar Oct	2		004		Heart Beat	1	*
001		Tine Pad	2		010		Mizmar Dual	2	G-800	005		Footsteps	1	***
002		Panner Pad	2		111	000	Fiddle	1		006		Applause 2	2	**
095	000	Halo Pad	2		008		Rababa	1	G-800	128	000	Gun Shot	1	***
096	000	Sweep Pad	1		112	000	Shanai	1		001		Machine Gun	1	***
001		Polar Pad	1		001		Shanai 2	1	V-SW	002		LaserGun	1	***
008		Converge	1		008		Pungi	1		003		Explosion	2	***
009		Shwimmer	2		016		Hichiriki	2						
010		Celestial Pd	2		<i>Percussive</i>									
<i>Synth SFX</i>					113	000	Tinkle Bell	1						
097	000	Ice Rain	2		008		Bonang	1						
					009		Gender	1						
					010		Gamelan Gong	1						

15.2 SC-55 Ton Listesi (C & D Bankaları)

PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark
Piano					016 Rubber Bass					Synth SFX				
001	000	Piano 1	1		Strings / Orchestra					097	000	Ice Rain	2	
	008	Piano 1w	1		041	000	Violin	1		098	000	Soundtrack	2	
	016	Piano 1d	1			008	Slow Violin	1		099	000	Crystal	2	
002	000	Piano 2	1		042	000	Viola	1			001	Syn Mallet	1	
	008	Piano 2w	1		043	000	Cello	1		100	000	Atmosphere	2	
003	000	Piano 3	1		044	000	Contrabass	1		101	000	Brightness	2	
	008	Piano 3w	1		045	000	Tremolo Str	1		102	000	Goblin	2	
004	000	Honky-tonk	2		046	000	Pizzicato	1		103	000	Echo Drops	1	
	008	HonkyTonk w	2		047	000	Harp	1			001	Echo Bell	2	
005	000	E.Piano 1	1		048	000	Timpani	1		002	Echo Pan	2		
	008	Detuned EP1	2		Ensemble					104	000	Star Theme	2	
	016	E.Piano 1v	2		049	000	Strings	1		Ethnic, etc.				
024	000	60s E.Piano	1			008	Orchestra	2		105	000	Sitar	1	
006	000	E.Piano 2	1		050	000	SlowStrings	1			001	Sitar 2	2	
	008	Detuned EP2	2		051	000	SynStrings1	1		106	000	Banjo	1	
	016	E.Piano 2v	2			008	SynStrings3	2		107	000	Shamisen	1	
007	000	Harpsichord	1		052	000	SynStrings2	2		108	000	Koto	1	
	008	Coupled Hps	2		053	000	Choir Aah	1			008	Taisho Koto	2	
	016	Harpsi.w	1		054	000	Choir Aahs2	1		109	000	Kalimba	1	
024	000	Harpsi.o	2		055	000	Voice Oohs	1		110	000	Bagpipe	1	
008	000	Clav.	1		056	000	SynVox	1		111	000	Fiddle	1	
						008	Orchest.Hit	2		112	000	Shanai	1	
Chromatic percussion					Brass					Percussive				
009	000	Celesta	1		057	000	Trumpet	1		113	000	Tinkle Bell	1	
010	000	Glockenspl	1		058	000	Trombone	1		114	000	Agogo	1	
011	000	Music Box	1			001	Trombone 2	2		115	000	Steel Drums	1	
012	000	Vibraphone	1		059	000	Tuba	1		116	000	Woodblock	1	
	008	Vib.w	1		060	000	Mute Trumpet	1			008	Castanets	1	
013	000	Marimba	1		061	000	French Horn	2		117	000	Taiko	1	
	008	Marimba w	1			001	Fr.Horn 2	2			008	Concert BD	1	
014	000	Xylophone	1		062	000	Brass 1	1		118	000	Melo. Tom 1	1	
015	000	Tubularbell	1			008	Brass 2	2			008	Melo. Tom 2	1	
	008	Church Bell	1		063	000	Syn.Brass 1	2		119	000	Synth Drum	1	
	009	Carillon	1			008	Syn.Brass 3	2			008	808 Tom	1	
016	000	Santur	1			016	Analog Brs1	2			009	Elec Perc	1	
Organ					064	000	Syn.Brass 2	2		120	000	Reverse Cym	1	
017	000	Organ 1	1			008	Syn.Brass 4	1		SFX				
	008	Detuned Or1	2			016	Analog Brs2	2		121	000	Gt.FretNoiz	1	
	016	60's Organ1	1		Reed						001	Gt.CutNoise	1	
032	000	Organ 4	2		065	000	Soprano Sax	1			002	String Slap	1	
018	000	Organ 2	1		066	000	Alto Sax	1		122	000	BreathNoise	1	
	008	Detuned Or2	2		067	000	Tenor Sax	1			001	Fl.KeyClick	1	
	032	Organ 5	2		068	000	BaritoneSax	1		123	000	Seashore	1	
019	000	Organ 3	2		069	000	Oboe	1			001	Rain	1	
020	000	Church Org1	1		070	000	EnglishHorn	1			002	Thunder	1	
	008	Church Org2	2		071	000	Bassoon	1			003	Wind	1	
	016	Church Org3	2		072	000	Clarinet	1			004	Stream	2	
021	000	Reed Organ	1		Pipe						005	Bubble	2	
022	000	Accordion F	2		073	000	Piccolo	1		124	000	Bird	2	
	008	Accordion I	2			000	Flute	1			001	Dog	1	
023	000	Harmonica	1		074	000	Recorder	1			002	HorseGallop	1	
024	000	Bandoneon	2		075	000	Pan Flute	1			003	Bird 2	1	
Guitar					076	000	Bottle Blow	2		125	000	Telephone 1	1	
025	000	Nylon Gt.	1		077	000	Shakuhachi	2			001	Telephone 2	1	
	008	Ukulele	1		078	000	Whistle	1			002	Creaking	1	
	016	Nylon Gt.o	2		079	000	Ocarina	1			003	Door	1	
032	000	Nylon Gt.2	1		Synth lead						004	Scratch	1	
026	000	Steel Gt.	1		081	000	Square Wave	2			005	Wind Chimes	2	
	008	12-str.Gt	2			001	Square	1		126	000	Helicopter	1	
	016	Mandolin	1			008	Sine Wave	1			001	Car-Engine	1	
027	000	Jazz Gt.	1		082	000	Saw Wave	2			002	Car-Stop	1	
	008	Hawaiian Gt	1			001	Saw	1			003	Car-Pass	1	
028	000	Clean Gt.	1			008	Doctor Solo	2			004	Car-Crash	2	
	008	Chorus Gt.	2		083	000	SynCalliope	2			005	Siren	1	
029	000	Muted Gt.	1			000	ChifferLead	2			006	Train	1	
	008	Funk Gt.	1		084	000	Charang	2			007	Jetplane	2	
	016	Funk Gt.2	1		085	000	Solo Vox	2			008	Starship	2	
030	000	OverdriveGt	1		086	000	5th Saw	2			009	Burst Noise	2	
031	000	Dist.Gt.	1		087	000	Bass & Lead	2		127	000	Applause	2	
	008	Feedback Gt	2		Synth Pad, etc.						001	Laughing	1	
032	000	Gt.Harmonix	1		088	000	Fantasia	2			002	Screaming	1	
	008	Gt.Feedback	1			090	Warm Pad	1			003	Punch	1	
Bass						091	Polysynth	2			004	Heart Beat	1	
033	000	Acoustic Bs	1			092	Space Voice	1			005	Footsteps	1	
034	000	Fingered Bs	1			093	Bowed Glass	2		128	000	Gun Shot	1	
035	000	Picked Bass	1			094	Metal Pad	2			001	Machine Gun	1	
036	000	Fretless Bs	1			095	Halo Pad	2			002	LaserGun	1	
037	000	Slap Bass 1	1			096	Sweep Pad	1			003	Explosion	2	
038	000	Slap Bass 2	1											
039	000	Syn.Bass 1	1											
	001	Syn.Bass101	1											
	008	Syn.Bass 3	1											
040	000	Syn.Bass 2	2											
	008	Syn.Bass 4	2											

15.3 Ton Listesi (CM-64 Tonları)

PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark	PC	CC00	Instrument	Voices	Remark
001	126	Piano 2	1		023	127	Celesta 1	1		111	127	Bottleblow	2	
002	126	Piano 2	1		024	127	Celesta 2	1		112	127	Breathpipe	1	
003	126	Piano 2	1		025	127	Syn Brass 1	2		113	127	Timpani	1	
004	126	Honky-tonk	2		026	127	Syn Brass 2	2		114	127	Melodic Tom	1	
005	126	Piano 1	1		027	127	Syn Brass 3	2		115	127	Deep Snare	1	
006	126	Piano 2	1		028	127	Syn Brass 4	2		116	127	Elec Perc 1	1	
007	126	Piano 2	1		029	127	Syn Bass 1	1		117	127	Elec Perc 2	1	
008	126	E.Piano 1	1		030	127	Syn Bass 2	2		118	127	Taiko	1	
009	126	Detuned EP1	2		031	127	Syn Bass 3	2		119	127	Taiko Rim	1	
010	126	E.Piano 2	1		032	127	Syn Bass 4	1		120	127	Cymbal	1	
011	126	Steel Gt.	1		033	127	Fantasy	2		121	127	Cascanets	1	
012	126	Steel Gt.	1		034	127	Harmo Pan	2		122	127	Triangle	1	
013	126	12-str.Gt	2		035	127	Chorale	1		123	127	Orche Hit	1	
014	126	Funk Gt.	1		036	127	Glasses	2		124	127	Telephone	1	
015	126	Muted Gt.	1		037	127	Soundtrack	2		125	127	Bird Tweet	1	
016	126	Slap Bass 1	1		038	127	Atmosphere	2		126	127	OneNote Jam	1	
017	126	Slap Bass 1	1		039	127	Warm Bell	2		127	127	Water Bell	2	
018	126	Slap Bass 1	1		040	127	Funny Vox	1		128	127	Jungle Tune	2	
019	126	Slap Bass 1	1		041	127	Echo Bell	2						
020	126	Slap Bass 2	1		042	127	Ice Rain	2						
021	126	Slap Bass 2	1		043	127	Ohoe 2001	2						
022	126	Slap Bass 2	1		044	127	Echo Pan	2						
023	126	Slap Bass 2	1		045	127	Doctor Solo	2						
024	126	Fingered Bs	1		046	127	School Daze	1						
025	126	Fingered Bs	1		047	127	Bellsinger	1						
026	126	Picked Bass	1		048	127	Square Wave	2						
027	126	Picked Bass	1		049	127	Str Sect 1	1						
028	126	Fretless Bs	1		050	127	Str Sect 2	1						
029	126	Acoustic Bs	1		051	127	Str Sect 3	1						
030	126	Choir Aahs	1		052	127	Pizzicato	1						
031	126	Choir Aahs	1		053	127	Violin 1	1						
032	126	Choir Aahs	1		054	127	Violin 2	1						
033	126	Choir Aahs	1		055	127	Cello 1	1						
034	126	SlowStrings	1		056	127	Cello 2	1						
035	126	Strings	1		057	127	Contrabass	1						
036	126	SynStrings3	2		058	127	Harp 1	1						
037	126	SynStrings3	2		059	127	Harp 2	1						
038	126	Organ 1	1		060	127	Guitar 1	1						
039	126	Organ 1	1		061	127	Guitar 2	1						
040	126	Organ 1	1		062	127	Elec Gtr 1	1						
041	126	Organ 2	1		063	127	Elec Gtr 2	1						
042	126	Organ 1	1		064	127	Sitar	2						
043	126	Organ 1	1		065	127	Acou Bass 1	1						
044	126	Organ 2	1		066	127	Acou Bass 2	1						
045	126	Organ 2	1		067	127	Elec Bass 1	1						
046	126	Organ 2	1		068	127	Elec Bass 2	1						
047	126	Trumpet	1		069	127	Slap Bass 1	1						
048	126	Trumpet	1		070	127	Slap Bass 2	1						
049	126	Trombone	1		071	127	Fretless 1	1						
050	126	Trombone	1		072	127	Fretless 2	1						
051	126	Trombone	1		073	127	Flute 1	1						
052	126	Trombone	1		074	127	Flute 2	1						
053	126	Trombone	1		075	127	Piccolo 1	1						
054	126	Trombone	1		076	127	Piccolo 2	2						
055	126	Alto Sax	1		077	127	Recorder	1						
056	126	Tenor Sax	1		078	127	Pan Pipes	1						
057	126	BaritoneSax	1		079	127	Sax 1	1						
058	126	Alto Sax	1		080	127	Sax 2	1						
059	126	Brass 1	1		081	127	Sax 3	1						
060	126	Brass 1	1		082	127	Sax 4	1						
061	126	Brass 2	2		083	127	Clarinet 1	1						
062	126	Brass 2	2		084	127	Clarinet 2	1						
063	126	Brass 1	1		085	127	Oboe	1						
064	126	Orchest.Hit	2		086	127	Engl Horn	1						
					087	127	Bassoon	1						
001	127	Acou Piano1	1		088	127	Harmonica	1						
002	127	Acou Piano2	1		089	127	Trumpet 1	1						
003	127	Acou Piano3	1		090	127	Trumpet 2	1						
004	127	Elec Piano1	1		091	127	Trombone 1	2						
005	127	Elec Piano2	1		092	127	Trombone 2	2						
006	127	Elec Piano3	1		093	127	Fr Horn 1	2						
007	127	Elec Piano4	1		094	127	Fr Horn 2	2						
008	127	Honkytonk	2		095	127	Tuba	1						
009	127	Elec Org 1	1		096	127	Brs Sect 1	1						
010	127	Elec Org 2	2		097	127	Brs Sect 2	2						
011	127	Elec Org 3	1		098	127	Vibe 1	1						
012	127	Elec Org 4	1		099	127	Vibe 2	1						
013	127	Pipe Org 1	2		100	127	Syn Mallet	1						
014	127	Pipe Org 2	2		101	127	Windbell	2						
015	127	Pipe Org 3	2		102	127	Glock	1						
016	127	Accordion	2		103	127	Tube Bell	1						
017	127	Harpsi 1	1		104	127	Xylophone	1						
018	127	Harpsi 2	2		105	127	Marimba	1						
019	127	Harpsi 3	1		106	127	Koto	1						
020	127	Clavi 1	1		107	127	Sho	2						
021	127	Clavi 2	1		108	127	Shakuhachi	2						
022	127	Clavi 3	1		109	127	Whistle 1	2						
					110	127	Whistle 2	1						

G-800 Drum Set program change map

1	STANDARD 1
2	STANDARD 2
9	ROOM
17	POWER
25	ELECTRONIC
26	TR-808/909
27	DANCE
33	JAZZ
41	BRUSH
49	ORCHESTRA
50	ETHNIC
51	KICK & SNARE
52	ARABIC
57	SFX
58	RHYTHM FX

SC-55 Drum Set program change map

1	STANDARD
9	ROOM
17	POWER
25	ELECTRONIC
26	TR-808
33	JAZZ
41	BRUSH
49	ORCHESTRA
57	SFX

15.4 GM Tonları

Piano

Tone #	Pg#	CC0#	Tone Name
A11	1	00	Piano 1
A12	2	00	Piano 2
A13	3	00	Piano 3
A14	4	00	Honky-tonk
A15	5	00	E.Piano 1
A16	6	00	E.Piano 2
A17	7	00	Harpechord
A18	8	00	Clav.

Ensemble

Tone #	Pg#	CC0#	Tone Name
A71	49	00	Strings
A72	50	00	Slow Strings
A73	51	00	Syn.Strings1
A74	52	00	Syn.Strings2
A75	53	00	Choir Aaha
A76	54	00	Voice Ooha
A77	55	00	SynVox
A78	56	00	OrchestraHit

Synth Sfx

Tone #	Pg#	CC0#	Tone Name
B51	97	00	Ice Rain
B52	98	00	Soundtrack
B53	99	00	Crystal
B54	100	00	Atmosphere
B55	101	00	Brightness
B56	102	00	Goblin
B57	103	00	Echo Drops
B58	104	00	Star Theme

Chr Perc.

Tone #	Pg#	CC0#	Tone Name
A21	9	00	Celesta
A22	10	00	Glockenspiel
A23	11	00	Music Box
A24	12	00	Vibraphone
A25	13	00	Marimba
A26	14	00	Xylophone
A27	15	00	Tubular-bell
A28	16	00	Santur

Brass

Tone #	Pg#	CC0#	Tone Name
A81	57	00	Trumpet
A82	58	00	Trombone
A83	59	00	Tuba
A84	60	00	MutedTrumpet
A85	61	00	French Horn
A86	62	00	Brass 1
A87	63	00	Synth Brass1
A88	64	00	Synth Brass2

Ethnic Misc

Tone #	Pg#	CC0#	Tone Name
B61	105	00	Sitar
B62	106	00	Banjo
B63	107	00	Shamisen
B64	108	00	Koto
B65	109	00	Kalimba
B66	110	00	Bag Pipe
B67	111	00	Fiddle
B68	112	00	Shanai

Organ

Tone #	Pg#	CC0#	Tone Name
A31	17	00	Organ 1
A32	18	00	Organ 2
A33	19	00	Organ 3
A34	20	00	Church Org.1
A35	21	00	Reed Organ
A36	22	00	Accordion Fr
A37	23	00	Harmonica
A38	24	00	Bandonion

Reed

Tone #	Pg#	CC0#	Tone Name
B11	65	00	Soprano Sax
B12	66	00	Alto Sax
B13	67	00	Tenor Sax
B14	68	00	Baritone Sax
B15	69	00	Oboe
B16	70	00	English Horn
B17	71	00	Bassoon
B18	72	00	Clarinet

Percussive

Tone #	Pg#	CC0#	Tone Name
B71	113	00	Tinkle Bell
B72	114	00	Agogo
B73	115	00	Steel Drums
B74	116	00	Woodblock
B75	117	00	Talko
B76	118	00	Melo. Tom 1
B77	119	00	Synth Drum
B78	120	00	Reverse Cym.

Guitar

Tone #	Pg#	CC0#	Tone Name
A41	25	00	Nylon-str.Gt
A42	26	00	Steel-str.Gt
A43	27	00	Jazz Gt.
A44	28	00	Clean Gt
A45	29	00	Muted Gt.
A46	30	00	Overdrive Gt1
A47	31	00	DistortionGt1
A48	32	00	Gt.Harmonics

Pipe

Tone #	Pg#	CC0#	Tone Name
B21	73	00	Piccolo
B22	74	00	Flute
B23	75	00	Recorder
B24	76	00	Pan Flute
B25	77	00	Bottle Blow
B26	78	00	Shakuhachi
B27	79	00	Whistle
B28	80	00	Ocarina

Sfx

Tone #	Pg#	CC0#	Tone Name
B81	121	00	Gt.FretNoise
B82	122	00	Breath Noise
B83	123	00	Seashore
B84	124	00	Bird
B85	125	00	Telephone 1
B86	126	00	Helicopter
B87	127	00	Applause
B88	128	00	Gun Shot

Bass

Tone #	Pg#	CC0#	Tone Name
A51	33	00	Acoustic Bs.
A52	34	00	Fingered Bs.
A53	35	00	Picked Bs.
A54	36	00	Fretless Bs.
A55	37	00	Slap Bass 1
A56	38	00	Slap Bass 2
A57	39	00	Synth Bass 1
A58	40	00	Synth Bass 2

Synth Lead

Tone #	Pg#	CC0#	Tone Name
B31	81	00	Square Wave
B32	82	00	Saw Wave
B33	83	00	Syn.Calliope
B34	84	00	Chiffer Lead
B35	85	00	Charging
B36	86	00	Solo Vox
B37	87	00	Sth Saw Wave
B38	88	00	Bass & Lead

DRUM SETS

Drum Set#	Pg#	CC0#	Set Name
1	1	00	Standard
2	9	00	Room
3	17	00	Power
4	25	00	Electronic
5	26	00	TR-808
6	41	00	Brush
7	49	00	Orchestra
8	57	00	SFX
9	33	00	Jazz

Strings

Tone #	Pg#	CC0#	Tone Name
A61	41	00	Violin
A62	42	00	Viola
A63	43	00	Cello
A64	44	00	Contrabass
A65	45	00	Tremolo Str
A66	46	00	PizzicatoStr
A67	47	00	Harp
A68	48	00	Timpani

Synth Pad

Tone #	Pg#	CC0#	Tone Name
B41	89	00	Fantasia
B42	90	00	Warm Pad
B43	91	00	Polysynth
B44	92	00	Space Voice
B45	93	00	Bowed Glass
B46	94	00	Metal Pad
B47	95	00	Halo Pad
B48	96	00	Sweep Pad

Tone# = Group / Bank / Number / Variation

Pg# = MIDI Program Change Number (1-128)

CC0# = MIDI Control Change 0, value (0-127)

15.5 GS Tonları

Piano

Tone #	Pg#	CC0#	Tone Name
A11	1	00	Piano 1
A111	08		Piano 1w
A112	16		Piano 1d
A12	2	00	Piano 2
A121	08		Piano 2w
A13	3	00	Piano 3
A131	08		Piano 3w
A14	4	00	Honky-tonk
A141	08		Honky-tonk w
A15	5	00	E.Piano 1
A151	08		Detuned EP 1
A152	16		E.Piano 1v
A154	24		60's E Piano
A16	6	00	E.Piano 2
A161	08		Detuned EP 2
A162	16		E.Piano 2v
A17	7	00	Harpichord
A171	08		Coupled Hps
A172	16		Harp w
A173	24		Harpst.o
A18	8	00	Clav.

Chr Perc.

Tone #	Pg#	CC0#	Tone Name
A21	9	00	Celesta
A22	10	00	Glockenspiel
A23	11	00	Music Box
A24	12	00	Vibraphone
A241	08		Vib.w
A25	13	00	Marimba
A251	08		Marimba w
A26	14	00	Xylophone
A27	15	00	Tubular-bell
A271	08		Church Bell
A272	09		Carillon
A28	16	00	Santur

Organ

Tone #	Pg#	CC0#	Tone Name
A31	17	00	Organ 1
A311	08		Detuned Or.1
A312	16		80's Organ 1
A313	32		Organ 4
A32	18	00	Organ 2
A321	08		Detuned Org.2
A322	32		Organ 5
A33	19	00	Organ 3
A34	20	00	Church Org.1
A341	08		Church Org.2
A342	16		Church Org.3
A35	21	00	Reed Organ
A36	22	00	Accordion Fr
A361	08		Accordion It
A37	23	00	Harmonica
A38	24	00	Bandoneon

Guitar

Tone #	Pg#	CC0#	Tone Name
A41	25	00	Nylon-str.Gt
A411	08		Ukulele
A412	16		Nylon Gt.o
A414	32		Nylon Gt.2
A42	26	00	Steel-str.Gt
A421	08		12-str.Gt
A423	16		Mandolin
A43	27	00	Jazz Gt.
A431	08		Hawaiian Gt.
A44	28	00	Clean Gt
A441	08		Chorus Gt.
A45	29	00	Muted Gt.
A451	08		Funk Gt.
A452	16		Funk Gt.2
A46	30	00	Overdrive Gt1
A47	31	00	DistortionGt1
A471	08		Feedback Gt.
A48	32	00	Gt.Harmonics
A481	08		Gt. Feedback

Bass

Tone #	Pg#	CC0#	Tone Name
A51	33	00	Acoustic Bs.
A52	34	00	Fingered Bs.
A53	35	00	Picked Bs.
A54	36	00	Fretless Bs.
A55	37	00	Slap Bass 1
A56	38	00	Slap Bass 2
A57	39	00	Synth Bass 1
A571	01		SynthBass101
A572	08		Synth Bass 3
A58	40	00	Synth Bass 2
A582	08		Synth Bass 4
A583	16		Rubber Bass

Strings

Tone #	Pg#	CC0#	Tone Name
A61	41	00	Violin
A611	08		Slow Violin
A62	42	00	Viola
A63	43	00	Cello
A64	44	00	Contrabass
A65	45	00	Tremolo Str
A66	46	00	PizzicatoStr
A67	47	00	Harp
A68	48	00	Timpani

Ensemble

Tone #	Pg#	CC0#	Tone Name
A71	49	00	Strings
A711	08		Orchestra
A72	50	00	Slow Strings
A73	51	00	Syn.Strings1
A731	08		Syn.Strings3
A74	52	00	Syn.Strings2
A75	53	00	Choir Aahs
A751	32		Choir Aahs 2
A76	54	00	Voice Oohs
A77	55	00	SynVox
A78	56	00	OrchestraHit

Brass

Tone #	Pg#	CC0#	Tone Name
A81	57	00	Trumpet
A82	58	00	Trombone
A821	01		Trombone 2
A83	59	00	Tuba
A84	60	00	MutedTrumpet
A85	61	00	French Horn
A851	01		French Horn 2
A86	62	00	Brass 1
A861	08		Brass 2
A87	63	00	Synth Brass1
A871	08		Synth Brass3
A872	16		AnalogBrass1
A88	64	00	Synth Brass2
A881	08		Synth Brass4

Reed

Tone #	Pg#	CC0#	Tone Name
B11	65	00	Soprano Sax
B12	66	00	Alto Sax
B13	67	00	Tenor Sax
B14	68	00	Baritone Sax
B15	69	00	Oboe
B16	70	00	English Horn
B17	71	00	Bassoon
B18	72	00	Clarinet

Pipe

Tone #	Pg#	CC0#	Tone Name
B21	73	00	Piccolo
B22	74	00	Flute
B23	75	00	Recorder
B24	76	00	Pan Flute
B25	77	00	Bottle Blow
B26	78	00	Shakuhachi
B27	79	00	Whistle
B28	80	00	Ocarina

Synth Lead

Tone #	Pg#	CC0#	Tone Name
B31	81	00	Square Wave
B311	01		Square
B312	08		Sine Wave
B32	82	00	Saw Wave
B321	01		Saw
B322	08		Doctor Solo
B33	83	00	Syn.Calliope
B34	84	00	Chiffer Lead
B35	85	00	Charang
B36	86	00	Solo Vox
B37	87	00	5th Saw Wave
B38	88	00	Bass & Lead

Synth Pad

Tone #	Pg#	CC0#	Tone Name
B41	89	00	Fantasia
B42	90	00	Warm Pad
B43	91	00	Polyseynth
B44	92	00	Space Voice
B45	93	00	Bowed Glass
B46	94	00	Metal Pad
B47	95	00	Halo Pad
B48	96	00	Sweep Pad

Synth Sfx

Tone #	Pg#	CC0#	Tone Name
B51	97	00	Ice Rain
B52	98	00	Soundtrack
B53	99	00	Crystal
B531	01		Syn Mallet
B54	100	00	Atmosphere
B55	101	00	Brightness
B56	102	00	Goblin
B57	103	00	Echo Drops
B571	01		Echo Bell
B572	02		Echo Pan
B58	104	00	Star Theme

Ethnic Misc

Tone #	Pg#	CC0#	Tone Name
B61	105	00	Sitar
B611	01		Sitar 2
B62	106	00	Banjo
B63	107	00	Shamisen
B64	108	00	Koto
B641	08		Taiko Koto
B65	109	00	Kalimba
B66	110	00	Bag Pipe
B67	111	00	Fiddle
B68	112	00	Shanai

Percussive

Tone #	Pg#	CC0#	Tone Name
B71	113	00	Tinkle Bell
B72	114	00	Agogo
B73	115	00	Steel Drums
B74	116	00	Woodblock
B741	08		Castanets
B75	117	00	Talko
B751	08		Concert BD
B76	118	00	Melo. Tom 1
B761	08		Melo. Tom 2
B77	119	00	Synth Drum
B771	08		808 Tom
B772	08		Elec Perc
B78	120	00	Reverse Cym.

Sfx

Tone #	Pg#	CC0#	Tone Name
B81	121	00	GLFretNoise
B811	01		GL Cth Noise
B812	02		String Slap
B82	122	00	Breath Noise
B821	01		FLKey Click
B83	123	00	Seashore
B831	01		Rain
B832	02		Thunder
B833	03		Wind
B834	05		Bubble
B84	124	00	Bird
B841	01		Dog
B842	02		Horse-Gallop
B843	03		Bird 2
B85	125	00	Telephone 1
B851	01		Telephone 2
B852	02		DoorCreaking
B853	03		Door
B854	04		Scratch
B86	126	00	Helicopter
B861	01		Car-Engine
B862	02		Car-Stop
B863	03		Car-Pass
B864	04		Car-Crash
B865	05		Siren
B866	06		Train
B867	07		Jetplane
B868	08		Starship
B869	09		Burst Noise
B87	127	00	Applause
B871	02		Screaming
B872	03		Punch
B873	04		Heart Beat
B874	05		Footsteps
B88	128	00	Gun Shot
B881	01		Machine Gun
B882	02		LaserGun
B883	03		Explosion

DRUM SETS

Drum Set#	Pg#	CC0#	Set Name
1	1	00	Standard
2	9	00	Room
3	17	00	Power
4	25	00	Electronic
5	26	00	TR-808
6	41	00	Brush
7	48	00	Orchestra
8	57	00	SFX
9*	33	00	Jazz

* (Only via MIDI)

Tone# = Group / Bank / Number / Variation

Bold: Capital Tones

Pg# = MIDI Program Change Number (1-128)

CC0# = MIDI Control Change 0, value (0-127)